
9. EXPLODED VIEWS AND PARTS LIST

NOTES:
- *Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.*
- *The ⚠ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.*
- *Screws adjacent to ▼ mark on product are used for disassembly.*
- *For the applying amount of lubricants or glue, follow the instructions in this manual. (In the case of no amount instructions, apply as you think it appropriate.)*

9.1 PACKING SECTION



(1) PACKING SECTION PARTS LIST


Mark	No.	Description	Part No.
	1	USB Cable	DDE1128
	2	CD-ROM (Installation Disc)	DXX2742
	3	Read Before Use (Important) /Quick Start Guide	See Contrast table (2)
	4	Read Before Use (Important) /Quick Start Guide	See Contrast table (2)
	5	Read Before Use (Important) /Quick Start Guide	See Contrast table (2)
	6	Read Before Use (Important) /Quick Start Guide	See Contrast table (2)
	7	Packing Sheet	AHG7053
	8	Pad/L	DHA1900
	9	Pad/R	DHA1901
	10	Packing Case	See Contrast table (2)
NSP	11	Polyethylene Bag	AHG7117
NSP	12	Warranty	See Contrast table (2)
	13	Label/IM1	See Contrast table (2)
NSP	14	Label/K	See Contrast table (2)

(2) CONTRAST TABLE

DDJ-SB/SXJ5, KXJ5 and XJCN5 are constructed the same except for the following:

Mark	No.	Symbol and Description	DDJ-SB /SXJ5	DDJ-SB /KXJ5	DDJ-SB /XJCN5
	3	Read Before Use (Important)/Quick Start Guide (En, Fr, De, It, Nl)	DRH1239	Not used	Not used
	4	Read Before Use (Important)/Quick Start Guide (Es, Po, Ru, Ja)	DRH1240	Not used	Not used
	5	Read Before Use (Important)/Quick Start Guide (Ko)	Not used	DRH1242	Not used
	6	Read Before Use (Important)/Quick Start Guide (Zhcn)	Not used	Not used	DRH1241
	10	Packing Case	DHG3289	DHG3300	DHG3299
NSP	12	Warranty	ARY7158	Not used	Not used
	13	Label/IM1	DRW2534	Not used	Not used
NSP	14	Label/K	Not used	DRW2600	Not used

9.2 EXTERIOR SECTION



EXTERIOR SECTION PARTS LIST

Mark	No.	Description	Part No.
	1	IFPW Assy	DWX3569
	2	PNL1 Assy	DWX3570
	3	PNL2 Assy	DWX3571
	4	CRFD Assy	DWX3573
	5	HOLD Assy	DWX3575
	6	FFC	ADD7796
	7	FFC/19P	DDD1671
	8	Leg/RBR	AEB1511
	9	Plate/JOG	DAH2981
	10	Gasket/JOG	DEC3539
	11	DS Tape/JOG	DEH1042
	12	Jog Dial	DNK6277
	13	Dial Knob S (B)	DAA1273
	14	Knob/PLS	DAA1324
	15	Slider Knob 1	DAC2684
	16	Slider Knob 2	DAC2685
	17	Button/BLK	DAC2950
	18	Button/MIX	DAC2951
	19	Button/OPL	DAC2952
	20	Button/PAD	DEB2009
	21	Fader Packing	DEC3355
	22	Sheet/PNL	DEC3543
	23	•••••	
	24	Stay/PCB	DNH3135
	25	Stay/FRT	DNH3136
	26	Plate/CND	DNH3137
	27	Plate/CHF	DNH3146
	28	Stopper/SLD	DNK6009
	29	Knob/SLD	DNK6283
	30	Control Panel	DNK6280
	31	Chassis	DNK6282
	32	•••••	
	33	•••••	
	34	Nut (M12)	NKX2FNI
	35	Washer	WA62D095D050
	36	Washer	YC60FAC
	37	Screw	BBZ30P060FTC
	38	Screw	BPZ30P080FNI
	39	Screw	BPZ30P100FTB
	40	Screw (M3*5)	DBA1340
	41	Screw	PMH20P040FTC

Pioneer

Service Manual

ORDER NO.
RRV4538

DJ Controller

DDJ-SB-S
DDJ-SB-R
DDJ-SB-L

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Model	Type	Power Requirement	Remarks
DDJ-SB-S	SXJ5	DC 5 V (USB-bus power only)	
DDJ-SB-R	SXJ5	DC 5 V (USB-bus power only)	
DDJ-SB-L	SXJ5	DC 5 V (USB-bus power only)	

This service manual should be used together with the following manual(s).

Model No.	Order No.	Remarks
DDJ-SB/SXJ5	RRV4503	

For SPECIFICATIONS and PANEL FACILITIES, refer to the operating instructions.

This product is a model derived from the DDJ-SB (base model) in a different color.
This product is the same as the DDJ-SB, except for the colors.
The major changes are as shown below.
Control Panel : Changed to silver (DDJ-SB-S), red (DDJ-SB-R), blue (DDJ-SB-L)
When replacing the above-mentioned parts, be sure to use the parts described in this manual.

PIONEER CORPORATION 1-1, Shin-ogura, Saiwai-ku, Kawasaki-shi, Kanagawa 212-0031, Japan
PIONEER ELECTRONICS (USA) INC. P.O. Box 1760, Long Beach, CA 90801-1760, U.S.A.
PIONEER EUROPE NV Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium
PIONEER ELECTRONICS ASIACENTRE PTE. LTD. 253 Alexandra Road, #04-01, Singapore 159936
ⓒ**PIONEER CORPORATION 2014**

K-ZZZ MAY 2014 Printed in Japan

1. CONTRAST OF MISCELLANEOUS PARTS

NOTES:
- *Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.*
- *The ⚠ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.*
- *Screws adjacent to ▼ mark on product are used for disassembly.*
- *For the applying amount of lubricants or glue, follow the instructions in this manual. (In the case of no amount instructions, apply as you think it appropriate.)*
- *Nos. indicate the pages and Nos. in the service manual for the base model.*

CONTRAST TABLE

DDJ-SB/SXJ5, DDJ-SB-S/SXJ5, DDJ-SB-R/SXJ5 and DDJ-SB-L/SXJ5 are constructed the same except for the following:

Mark	No.	Symbol and Description	DDJ-SB/SXJ5	DDJ-SB-S/SXJ5	DDJ-SB-R/SXJ5	DDJ-SB-L/SXJ5	Remarks
		PACKING SECTION					
	P45-10	Packing Case	DHG3368	DHG3337	DHG3333	DHG3335	
NSP		Label/S	Not used	DRW2623	Not used	Not used	
NSP		Label/R	Not used	Not used	DRW2628	Not used	
NSP		Label/L	Not used	Not used	Not used	DRW2629	
		EXTERIOR SECTION					
	P47-30	Control Panel	DNK6280	DNK6341	DNK6347	DNK6319	